

EduTouch SX Home Screen Quick Reference Guide



- 1** Swipe up from the centre to access the **Input Sources**, **Volume** and **Brightness**.
- 2** Access the **Home Screen**, **Go Back**, **Open Apps**, **Insert Window** and **Annotation** tools on the **Sidebar**.
- 3** Swipe up from the left or right hand corners to display the **Tools** menu.
- 4** Displays if an optional built-in **computer** is installed.